

SUBWOOFER SETUP NOTES:

In an effort to keep the setup of your subwoofer simple when used with a surround sound receiver or processor, set all subwoofer back panel controls and switches to the position marked with a GREEN dot. The VARIABLE LOW PASS FILTER is the only control without a green dot as its function is bypassed when the LOW PASS FILTER switch is in the BYPASS/OFF position with the GREEN dot.

LOGO:

The Kreisel logo affixed to the cabinet front has been designed to allow for rotating 180 degrees. This will be useful when stacking multiple subwoofers together (Please see the latest operation manual available for download at support at www.kreiselound.com for more details about stacking subwoofers).

Steps to permanently mount the logo

- 1) Remove logo from the cabinet
- 2) Peel off the paper coating covering the 3M adhesive
- 3) Replace logo in preferred orientation and press firmly in place
- 4) The adhesive will now permanently hold the logo in place

